

WS7000 Touchless-Dispense Foot Pedal Installation Guide


Below are instructions for installing the WS7000 Touchless-Dispense Foot Pedal. It can be ordered with part number: WS7000FTPDLK.




WHAT TO DO:



Step 1: Remove the lower front panel and gain access to the main board



Step 2: Look for this wire located near the mail board.



Step 3: Disconnect the blue and white wire connectors and connect them to the foot pedal harness as pictured above.

Step 4: The wire harness that connects the foot pedal should be routed through the unit to connect to the foot pedal.'

Note: Be sure to position the pedal and route the wire from the foot pedal into the machine to that there is no excess wiring that could case a tripping hazard.

Step 5: Test and reassemble the unit.



For additional tips or assistance, contact Wellsys technical support directly:
855-558-9796 - option 3

wellsys 